

**E868 / E758 OSD default setting**

Menu / Sub Menu	Default
<b>Video</b>	
Picture Mode	Energy Savings
<b>Advanced Video</b>	
Aspect Ratio	Normal
Overscan	Off
Dimming Setting	Depends on Picture Mode
Color Temperature	Depends on Picture Mode
Noise Reduction	Depends on Picture Mode
Adaptive Contrast	Depends on Picture Mode
Gamma	Depends on Picture Mode
Ambient Light Sensing	Depends on Picture Mode
Color Enhance	Depends on Picture Mode
HDR Mode	Depends on Picture Mode
Backlight	Depends on Picture Mode
Contrast	Depends on Picture Mode
Video Black Level	Depends on Picture Mode
Sharpness	Depends on Picture Mode
Color	Depends on Picture Mode
Tint	Depends on Picture Mode
Reset Video Settings	No

<b>Audio</b>	
Sound Mode	Standard
Balance	0
Sorround	Off
Internal Speakers	Auto
Digital Output	RAW
Audio Input	When Input (HDMI1) : HDMI 1
	When Input (HDMI2) : HDMI 2
	When Input (HDMI3) : HDMI 3
	When Input (VGA) : Audio in
	When Input (AV) : AV
	When Input (Media Player) : Media Player(Fixed)
Audio Delay	0
Reset Audio Settings	No

## Setup

## OSD Settings

Language	English
Transparency	Off
Information OSD	On

## Closed Caption

\*Valid when Input(AV)

Caption Display	CC Off
Analog Captions	CC1

## Power save settings

Energy Mode	Home
Power Save	1 minute
Quick Start	Off
Auto Power Down	Off

## Auto Input Change

None

## HDMI Settings

CEC	
CEC	On
Auto Turn Off	Enable
Audio Receiver	Disable
EDID	Mode 2
Video Range	Auto
HPD Delay	Off

## VGA Options

VGA Mode	RGB
Auto Adjust	Press OK to execute
Horizontal Position	Depending on Auto Adjust
Vertical Position	Depending on Auto Adjust
Clock	Depending on Auto Adjust
Phase	Depending on Auto Adjust
H. Resolution	Depending on Auto Adjust
V. Resolution	Depending on Auto Adjust
Reset VGA Options	No

## Other Settings

Input Labels	Same as Input Name
Key Lock Settings	Off
IR Lock Settings	Off
Power Supply	Off
LED Indicator	On
Mute Settings	Audio
Image Rotation	Off
Thermal Management	
Warning Message	On
Shutdown	On
Signal Information	Depending on source signal

## Monitor Information

Depends on set

## Factory Reset

No

Control Settings	
Control Interface	LAN
Network Settings	
DHCP	On
IP ADDRESS	xxx.xxx.xxx.xxx
SUBNET MASK	xxx.xxx.xxx.xxx
DEFAULT GATEWAY	xxx.xxx.xxx.xxx
DNS PRIMARY	xxx.xxx.xxx.xxx
DNS SECONDARY	xxx.xxx.xxx.xxx
MAC ADDRESS	Individual
SAVE	Press OK to execute
Monitor ID	1
Reset Network Settings	No
Media Player	
USB Demo Mode	Off
UnPlug USB Device	Enabled when USB device is attached
Caution Window	On
Schedule	
Sleep Timer	Off
Current Time settings	N/A
Schedule settings	
Power On	Mark (Disable)
	12:00
Power Off	Mark (Disable)
	12:00