

Menu / Sub Menu	Default
Video	
Picture Mode	Energy Savings
Advanced Video	
Aspect Ratio	Normal
Overscan	Off
Dimming Setting	Depends on Picture Mode
Color Temperature	Depends on Picture Mode
Noise Reduction	Depends on Picture Mode
Adaptive Contrast	Depends on Picture Mode
Gamma	Depends on Picture Mode
Ambient Light Sensing	Depends on Picture Mode
Color Enhance	Depends on Picture Mode
HDR Mode	Depends on Picture Mode
Backlight	Depends on Picture Mode
Contrast	Depends on Picture Mode
Video Black Level	Depends on Picture Mode
Sharpness	Depends on Picture Mode
Color	Depends on Picture Mode
Tint	Depends on Picture Mode
Reset Video Settings	No

Audio	
Sound Mode	Standard
Balance	0
Sorround	Off
Internal Speakers	Auto
Digital Output	RAW
Audio Input	When Input (HDMI1) : HDMI 1
	When Input (HDMI2) : HDMI 2
	When Input (HDMI3) : HDMI 3
	When Input (VGA) : Audio in
	When Input (AV) : AV
	When Input (Media Player) : Media Player(Fixed)
Audio Delay	0
Reset Audio Settings	No

Setup	
OSD Settings	
Language	English
Transparency	Off
Information OSD	On
Closed Caption <span style="float: right;">*Valid when Input(AV)</span>	
Caption Display	CC Off
Analog Captions	CC1
Power save settings	
Energy Mode	Home
Power Save	1 minute
Quick Start	Off
Auto Power Down	Off
Auto Input Change	None
HDMI Settings	
CEC	
CEC	On
Auto Turn Off	Enable
Audio Receiver	Disable
EDID	Mode 2
Video Range	Auto
HPD Delay	Off
VGA Options	
VGA Mode	RGB
Auto Adjust	Press OK to execute
Horizontal Position	Depending on Auto Adjust
Vertical Position	Depending on Auto Adjust
Clock	Depending on Auto Adjust
Phase	Depending on Auto Adjust
H. Resolution	Depending on Auto Adjust
V. Resolution	Depending on Auto Adjust
Reset VGA Options	No
Other Settings	
Input Labels	Same as Input Name
Key Lock Settings	Off
IR Lock Settings	Off
Power Supply	Off
LED Indicator	On
Mute Settings	Audio
Image Rotation	Off
Thermal Management	
Warning Message	On
Shutdown	On
Signal Information	Depending on source signal
Monitor Information	Depends on set
Factory Reset	No

Control Settings		
Control Interface		LAN
Network Settings		
DHCP	On	
IP ADDRESS	xxx.xxx.xxx.xxx	
SUBNET MASK	xxx.xxx.xxx.xxx	
DEFAULT GATEWAY	xxx.xxx.xxx.xxx	
DNS PRIMARY	xxx.xxx.xxx.xxx	
DNS SECONDARY	xxx.xxx.xxx.xxx	
MAC ADDRESS	Individual	
SAVE	Press OK to execute	
Monitor ID	1	
Reset Network Settings	No	
Media Player		
USB Demo Mode	Off	
UnPlug USB Device	Enabled when USB device is attached	
Caution Window	On	
Schedule		
Sleep Timer	Off	
Current Time settings	Current time and date can be changed	
Schedule settings (1 to 7)		
Power On	Mark (Disable)	
Time		12:00
Power Off	Mark (Disable)	
Time		12:00
Every Day	Mark (Disable)	
Every Week	Mark (Disable)	
Mon	Mark (Disable)	
Tue	Mark (Disable)	
Wed	Mark (Disable)	
Thu	Mark (Disable)	
Fri	Mark (Disable)	
Sat	Mark (Disable)	
Sun	Mark (Disable)	